tail vein is along the lateral side of the tail.
Blood can be collected from, or substances administered via the retroorbital sinus only when mice are isoflurane anesthetized .
Intravenous (IV) administrations IV aufministrations over time requires planning to preserve access.
Demonstrate/Assess:
Tail Vein (IV) Injection
Place mouse in a 50ml conical tube with air holes drilled in it. Secure the mouse in the restrainer to a raised surface.
Paint warm water over the target vein with cotton tipped applicator stick.
Use a 27-30g needle or 27g butterfly catheter for multiple dosing.